


**MAXXUM 46T**  
**46 LBS. THRUST**  
**12 VOLT 42 AMPS**  
**36" SHAFT**

**for use with "AI" serial numbers**  
**3-year warranty from the date of purchase**




1	2-100-116	ARMATURE ASSEMBLY 12V F/W	37	2062800	TENSION BLOCK-SNAP IN
2	788-015	RETAINING RING	38	2011385	SCREW, TENSION/KNOB
3	140-010	BEARING -BALL	39	2060515	PIN, TILT LEVER
4	431-101	HOUSING ASSEMBLY CENTER 3.62	40	2061520	COLLAR-DEPTH
5	421-065	HOUSING BRUSH END ASSEMBLY 3.62 TXT	41	2011365	SCREW-COLLAR/NEW
6	2-400-101	PLAIN END HOUSING ASSEMBLY	42	2052900	STRAIN RELIEF C CORD/SP.C
7	144-049	FLANGE BEARING (SERVICE ONLY)	43	2090600	LEADWIRE (10 GA) RINGS
8	880-003	SEAL	43A	2307310	BEAD - FERRITE (CE MODELS ONLY)
9	880-006	SEAL W/SHIELD	44	2062592	CONTROL BOX,FW, .725 BORE,
10	188-036	BRUSH ASSEMBLY	45	2074070	BATTERY GAUGE-12 VOLTS
11	725-050	PAPER TUBE- BRUSH RETENTION	46	2303120	SPEED NUT [2.EA]
12	738-036	BRUSH PLATE W/HOLDER	47	2061515	COLLAR-CTRL BOX (FRS-WTR)
13	975-040	SPRING -TORSION [2.EA]	48	2990294	CTRL BOX CVR/DECAL ASSEMBLY
14	337-036	GASKET	49	2065666	DECAL-COVER MAX 46/T
15	701-008	O-RING -THRU BOLT [2.EA]	50	2990914	HANDLE ASSEMBLY W/O U-JOINT
16	701-081	O-RING	51	2302742	SPRING-DETENT (OFF) SS
17	830-007	SCREW 8-32X1 [2.EA]	52	2302743	SPRING-DETENT (HANDLE-TILT
18	830-042	THRU BOLT 10-32X8.83 (2 EA)	53	2303412	SCREW-6-20 X 5/8 SELF TAP [6.EA]
19	990-067	WASHER -STEEL THRUST	54	2302745	SPRING-RELEASE BUTTON SS
20	990-070	WASHER -NYLATRON [2.EA]	55	2303720	RELEASE BUTTON-HANDLE
21	2097063	MOTOR ASSEMBLY -12V 3.625 F/W VARS TXT	56	2060409	HANDLE (TOP HALF) MAXIMIZE
22	2032052	TUBE (COMPOSITE) 36"	57	2060415	HANDLE (LOWER HALF)
■	1378131	PROPELLER KIT	58	2303412	SCREW-6-20 X 5/8 SELF TAP [5.EA]
23	2091160	PROPELLER- WEEDLESS WEDGE 2	59	2060005	BEARING-HANDLE PIVOT [2.EA]
24	2151726	WASHER- 5/16 STD SS	60	2184020	POT ADAPTER
25	2053101	NUT-PROP NYLOC 5/16 SS	61	2992852	ACTUATOR-CAM
26	2092600	PIN-DRIVE SS	64	2181700	WASHER, SPACER
■	2771818	BRACKET & HINGE ASSEMBLY (INCLUDES- 28—39)	65	2184004	CONTROL BOARD 12V
■	2771910	BRACKET ASSEMBLY (INCLUDES- 28,30,31)	66	2256300	TIE WRAP-5.5 BLACK
*28	2061910	BRACKET- PLASTIC	67	2043427	SCREW-8-18 X 7/8 THD SS [2.EA]
29	2060510	PIN-HINGE	68	2383407	SCREW-10-24 X 2 PPH ZINC
■	2881300	SCREW-CLAMP, WASHER, RETAINER KIT [2.EA]	69	2383124	NUT-10-24 NYLOCK ZINC
*30	2061300	SCREW-CLAMP [2.EA]	70	2043427	SCREW-8-18 X 7/8 SS [2.EA]
*31	2011710	WASHER-CLAMP SCREW [2.EA]	72	2020700	TERMINAL- RING 3/8 [2.EA]
32	2063605	T-BAR, PLASTIC	73	2263434	SCREW #8 X 1" PPH SS [2.EA]
33	2062706	SPRING- (T-BAR)			
34	2067200	LEVER-TILT (RED)			
35	2061810	HINGE-PLASTIC			2888460 seal & oring kit
36	2037301	BUSHING-HINGE [2.EA]			

\* This item is part of an assembly. This item cannot be sold separately due to machining and /or assembly that is required.

# Maxxum 46T is 12-volt only!

wiring diagram for control board #2184002:



wiring diagram for control board #2184004:

